



NOTES:

1. PVC LATERAL SHALL BE ABANDONED BY CUTTING THE PIPE NEAR THE WYE AND INSTALLING A WATERPROOF PVC CAP ON THE PIPE ENDS. ABANDON ALL OTHER PIPES BY CUTTING THE PIPE NEAR THE WYE AND SEALING THE PIPE ENDS WITH A FERNCO FLEXIBLE COUPLING AND PVC PLUG.
2. ABANDON THE REMAINDER OF THE EXISTING PIPE WITHIN 5' OF THE BACK OF CURB OR EDGE OF SHOULDER BY FILLING WITH A FLOWABLE FILL. FLOWABLE FILL SHALL BE CONCRETE, SLURRY OR APPROVED EQUAL.

SCALE: NTS

**SANITARY LATERAL ABANDONMENT AT
EXISTING MAIN**

DETAIL: SAN - 6

DATE: 4-22-20

APPROVED BY: MATT FINEOUR

**VILLAGE OF PLEASANT PRAIRIE
KENOSHA COUNTY, WISCONSIN**